

TWO YEAR LIMITED WARRANTY

(Valid in USA only)

HoMedics, Inc., guarantees this product free from defects in material and workmanship for a period of two years from the date of original purchase, except as noted below.

This HoMedics product warranty does not cover damage caused by misuse or abuse; accident; the attachment of any unauthorized accessory; alteration to the product; or any other conditions whatsoever that are beyond the control of HoMedics. This warranty is effective only if the product is purchased and operated in the USA. A product that requires modification or adaptation to enable it to operate in any country other than the country for which it was designed, manufactured, approved and/or authorized, or repair of products damaged by these modifications is not covered under warranty. HoMedics shall not be responsible for any type of incidental, consequential or special damages. All implied warranties, including but not limited to those implied warranties of fitness and merchantability, are limited in the total duration of two years from the original purchase date.

To obtain warranty service on your HoMedics product, either hand deliver or mail the unit and your dated sales receipt (as proof of purchase), postpaid, along with check or money order in the amount of \$5.00 payable to HoMedics, Inc. to cover handling.

Upon receipt, HoMedics will repair or replace, as appropriate, your product and return it to you, postpaid. If it is appropriate to replace your product, HoMedics will replace the product with the same product or a comparable product at HoMedics' option. Warranty is solely through HoMedics Service Center. Service of this product by anyone other than HoMedics Service Center voids warranty.

This warranty provides you with specific legal rights. You may have additional rights which may vary from state to state. Because of individual state regulations, some of the above limitations and exclusions may not apply to you.

For more information regarding our product line in the USA, please visit:
www.homedics.com

Luxury Foot Spa
FootREJUVENATOR™*with Wet & Dry Massage Center***Instruction Manual and
Warranty Information**

FR-500

Indulge your feet, reduce daily stress.

Thank you for purchasing Foot Rejuvenator, HoMedics' Bubble Footbath with Infrared and Massage Spinners. This, like all of HoMedics' products, is built with high-quality craftsmanship and comes backed by our two-year limited warranty. Foot Rejuvenator is guaranteed to provide you soothing massage relief for years to come.

HoMedics is dedicated to bringing you better health through innovation. However, you should never substitute this, or any other manufacturer's product, for professional medical attention. Persistent ailments and symptoms could indicate a more serious condition.

IMPORTANT SAFETY INSTRUCTIONS: WHEN USING ELECTRICAL PRODUCTS, ESPECIALLY WHEN CHILDREN ARE PRESENT, BASIC SAFETY PRECAUTIONS SHOULD ALWAYS BE FOLLOWED, INCLUDING THE FOLLOWING:

READ ALL INSTRUCTIONS BEFORE USING.

DANGER - TO REDUCE THE RISK OF ELECTRIC SHOCK:

- ALWAYS unplug the appliance from the electrical outlet immediately after using and before cleaning.

WARNING - TO REDUCE THE RISK OF BURNS, ELECTRIC SHOCK, FIRE OR INJURY TO PERSONS:

- Close supervision is necessary when this appliance is used by, on or near children, invalids, or disabled persons.
- DO NOT operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged or dropped into water. Return the product to HoMedics Service Center for examination and repair.
- Keep cord away from heated surfaces.
- An appliance should NEVER be left unattended when plugged in. Unplug from outlet when not in use, and before putting on or taking off parts.
- DO NOT operate under blanket or pillow. Excessive heating can occur and cause fire, electric shock, or injury to persons.
- DO NOT carry this appliance by supply cord or use cord as a handle.
- NEVER operate the appliance with the air openings blocked. Keep the air openings free of lint, hair and the like.
- NEVER drop or insert any object into any opening.
- DO NOT use outdoors.
- DO NOT operate where aerosol (spray) products are being used or where oxygen is being administered.
- To disconnect, turn all controls to the off position, then remove the plug from outlet.
- Use this appliance only for its intended use as described in this manual. DO NOT use attachments not recommended by HoMedics.
- DO NOT attempt to stand on or in your HoMedics foot bath. Use only while seated.
- Connect this appliance to a properly grounded outlet only. See Grounding Instructions.

Caution:
All servicing of this
footbath must be
performed by
authorized
HoMedics
service personnel
only.

SAVE THESE INSTRUCTIONS

SPECIAL WARNINGS

- DO NOT reach for an appliance that has fallen into water. Unplug it immediately.
- DO NOT use while bathing or showering.
- DO NOT place or store appliance where it can fall or be pulled into a tub or sink. DO NOT place in or drop into water or other liquid.
- DO NOT attempt to plug or unplug unit while feet are in the water.
- Use appliance on a sturdy or level surface.
- If you have any concerns regarding your health, consult your doctor before using your HoMedics foot bath.
- Individuals with pacemakers should consult a physician before using this product.
- In case of pregnancy, diabetes or illness, consult your doctor before using massager.
- We recommend using this unit for no longer than 20 minutes at a time. Extensive use could cause the product to overheat. Should this occur, discontinue use and allow the unit to cool before operating.
- If you experience pain in a muscle or joint for a prolonged period of time, discontinue use and consult your doctor. Persistent pain could be a symptom of a more serious condition.
- NEVER use any massager on open wounds, discolored areas, or any area of the body that is swollen, burned, inflamed or where skin eruptions or sores are present.
- Massage should be pleasant and comfortable. Should pain or discomfort result, discontinue use and consult your physician.




Figure A




Figure B




Figure C




Figure D




Figure E

- NEVER use while sleeping or drowsy.
- Always unplug the unit when filling or moving the unit.
- Ensure that your hands are dry when operating the switch or removing the plug.

Grounding Instructions

This product must be grounded. If it should malfunction or breakdown, grounding provides a path of least resistance for the electric current to reduce the risk of electric shock. This product is equipped with a cord having an equipment-grounding conductor and a grounding plug. The plug must be plugged into an appropriate outlet that is properly installed and grounded in accordance with all local codes and ordinances.

DANGER

Improper connection of the equipment-grounding conductor can result in a risk of electric shock. Check with a qualified electrician or serviceman if you are in doubt as to whether the product is properly grounded. Do not modify the plug provided with the product - if it will not fit the outlet, have a proper outlet installed by a qualified electrician.

This product is for use on a nominal 120-volt circuit, and has a grounding plug that looks like the plug illustrated in **Figure A**.

A temporary adapter that looks like the adapter illustrated in **Figure B** may be used to connect this plug to a 2-pole receptacle as shown in **Figure D** if a properly grounded outlet is not available. The temporary adapter should be used only until a properly grounded outlet **Figure C** can be installed by a qualified electrician. The green-colored tab extending from the adapter must be connected to a permanent ground such as a properly grounded outlet box cover. Whenever the adapter is used, it must be held in place by a metal screw. **See Figures D and E.**

Foot Rejuvenator Features

- Wet or Dry Massage - Choose from bubbling water massage or spinning dry massage
- Massaging Spinners - A touch of your foot spins the massaging rollers.
- Double the Bubbles - Unique serpentine track provides double the bubbles.
- Foot Activated Controls - Just a touch of the toe turns bath on and off.
- Soothing Heat - Helps maintain warm water temperature for a soothing foot bath.
- Infrared Heat - Provides deep penetrating therapy to the soles of your feet.
- Acupressure Surface - Hundreds of tiny nodules stimulate your feet.

Instructions for Use

1. Ensure that the unit is unplugged before filling with water. Be sure to fill no higher than fill line indicator on inner tub (See Figure 1).
2. Plug into a 120V AC household outlet. Turn the function dial to indicate the massage of your choice.

0 OFF

1 Massage/Heat/Infrared


2 Massage/Bubbles/Heat/Infrared

3 Bubbles/Heat

3. Sit down and place your feet in the spa.

4. To enjoy the spinning massagers, simply press the spinners on/off button to turn on. Press button a second time for a faster speed. Set your feet on top of the rollers for a relaxing massage. DO NOT STAND ON SPINNING MASSAGERS. Press the on/off button a third time to turn spinners off. **NOTE: Spinning massagers can be used without water in the tub for a dry massage.**
5. To use the infrared function for deep penetrating heat therapy to the soles of your feet, select # 1 OR #2 and place foot over the center console. Use more or less pressure to adjust for comfort.
6. Enjoy a deep penetrating massage by sliding feet back and forth over the acupressure surface on the footbath floor and infrared.
7. To empty: First, unplug the unit. Tip the unit, allowing water to spill out along the drain spout. Never pour water over the control switch. (See Figure 1).

Figure 1



CAUTION: DO NOT FILL WATER OVER THE FILL LINE

FootREJUVENATOR™

Wet & Dry Massage Center

Note: Heat will help to maintain the temperature of the water placed inside this foot-bath. It will not heat cold water. For a warm water massage, please fill the unit with warm water.

Maintenance

To Clean

Unplug the unit and allow it to cool before cleaning. Clean only with a soft, damp cloth. Never allow water or any other liquid to come into contact with the control switch.

- After cleaning, wipe surfaces with a dry cloth.
- Never use abrasives, detergents or cleaning agents.
- Periodically straighten cord if it becomes twisted.

To Store

Unplug the appliance from the outlet and allow to cool.

- Store in its box or a clean, dry place.
- To avoid breakage, do not wrap the power cord around the unit.
- Do not hang the unit by the power cord.
- This appliance is designed for household use only.

Convenient Drain Spout

For easy emptying.

Massaging Spinners

Spinning rollers soothe away stress.



Serpentine Bubble Track

Special track design consists of double the air vents to double the bubbles.

Infrared Heat

Deep penetrating heat therapy to the soles of your feet.

Rejuvenating Massage

To stimulate the soles of your feet.

Invigorating Bubbles

Thousands of bubbles help release muscle tension.

Soothing Heat

Helps maintain warm water temperature.

Acupressure Surface

Hundreds of nodules help stimulate the soles of your feet.



Extra Long Cord

For convenient extended use.